


Large Modern Bench Plans



Materials List:


- 1 - 1x12x6'
- 3 - 1x3x8'
- 1 - 1x3x10'

Cut List:

- 1 - 1x12 @ 60"
- 8 - 1x3 @ 28 1/8"
- 6 - 1x3 @ 18" ends mitered at 13 degrees off square, ends parallel
- 3 - 1x3 @ 5 7/8" (shortest side) ends mitered at 13 degrees off square, ends not parallel
- 3 - 1x3 @ 12 1/4" (shortest side) ends mitered at 13 degrees off square, ends not parallel


Step 1:

Make three legs with the mitered 1x3s as shown in the picture! Pocket hole placement can be seen on the blog tutorial but you will drill them at 3/4" and use wood glue and 1 1/4" screws to attach. Its hard to see in the picture, but the bottom 1x3 is raised 1 1/4" from the bottom of the leg.





Step 2:

Attach the legs to the 1x12 using wood glue and 1 1/4" screws! I attached the stretchers as I went as you will see in my blog tutorial! Just to make sure they stayed exactly 28 1/8" apart. I inset the side legs 3/4".



Step 3:

Attach the top stretchers. They didn't as you holes are drilled attached with ample wood glue. I pocket holed the 1x12 as



Step 4:

Attach the bottom stretchers. They are only pocket holed into the legs. And it is done! I love a project so cute but yet so easy! Sand and stain to your heart's delight!