

DIY Small Modern Bench




Materials:


- 1 - 1x12x4'
- 2 - 1x2x8'

Cut List:

- 1 - 1x12 @ 30"
- 4 - 1x2 @ 15" mitered at 13 degrees off square ends parallel
- 4 - 1x2 @ 28 1/2"
- 2 - 1x2 @ 7 1/2" mitered at 13 degrees off square ends not parallel
- 2 - 1x2 @ 13" mitered at 13 degrees off square ends not parallel


Step 1: Build the legs! You will build two of the legs shown below. You will drill pocket holes at 3/4" deep and use wood glue and 1 1/4" screws to attach. For placement of pocket holes please see blog post as it would be confusing to place them on the sketchup I felt!





Step 2:
Attach legs to bench top
(1x12)

Step 3:
Add top stretchers! Refer to the blog post
to see where to drill pocket holes! Same
3/4" pocket holes and 1 1/4" screws and
wood glue will be used on all parts of this
build.



Step 4:
Attach bottom stretchers!

